




Enter/Exit Programming Mode



Scale Enforced Zero Return = Disable



Scale Sentry = Disable



Enter/Exit Programming Mode